

# Work Order ID 72559

Friday, July 29, 2011 11:28:02 AM



Page 1

Item ID: D350-567-025

Accept



Setup Start



Revision ID:

Stop



Item Name: Floor Window Installation, Large

Start Date: 7/29/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 7/29/2011 Req'd Qty: 1.00



Customer:

Reference:

Run Start



Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_

Stop



QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr	Revision Nbr
----------	--------------

N/A	Rev D
-----	-------

100

0.00



DOCUMENT CONTROL

DC

Memo

0.00

Document Control

Copy bluefile and create labels & DT8439 per PPP D350-567-025 CHG002

*5 ulcr/x*

*JA for BG 11-7-29*

110

0.00



Packaging

Packaging

Memo

0.00

Packaging

Pick Packing Kit\*\*\*ENSURE DT 8439 TEMPLATE IS INCLUDED\*\*\*

*P417/29*

120

QC4- 100% Inspect kits for completeness

0.00



QC

Memo

0.00

Quality Control

*5 ulcr/29*

*20*

**Work Order ID 72559**

Page 2

Friday, July 29, 2011 11:28:02 AM

Item ID: D350-567-025

Accept



Setup Start



Revision ID:

Stop



Item Name: Floor Window Installation, Large

Start Date: 7/29/2011 Start Qty: 1.00



Cust Item ID:

Required Date: 7/29/2011 Req'd Qty: 1.00



Customer:

Reference:

Approvals: Process Plan: \_\_\_\_\_ Date: \_\_\_\_\_ Tooling: \_\_\_\_\_ Date: \_\_\_\_\_

Run Start



QC: \_\_\_\_\_ Date: \_\_\_\_\_ SPC (Y/N): \_\_\_\_\_ Date: \_\_\_\_\_

Stop



Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

130

0.00



Packaging

Packaging

Memo

0.00

Packaging

Identify and pack for shipping as per PPP D350-567-

025 ☐ Location: \_\_\_\_\_ ☐ PPP Rev: \_\_\_\_\_☐\*\*\*\*\*Ensure DT8439 template is included in  
kit\*\*\*\*\*

140

QC21- Final Inspection - Work Order Release

0.00



QC

Memo

0.00

Quality Control




Friday, July 29, 2011 11:28:00 AM

[illegible][illegible]

**Required Date:** 7/29/2011

**Required Qty: 1.00**

**Comments:** IPP Rev:B Added Cutting Template 05-12-14 JLM  
IPP Rev:C 08-10-07 as per revD DD verified by:

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
D350-567-023 	CHC702	Manufactured	No			120	Each	0.0000	1	1			
Replacement Window, Large													
D350-567-031 	CHC701	Manufactured	No			120	Each	1.0000	1	1			
Interior Floor Window (Sliding Door Compatible)													
				<u>Location</u>		<u>Loc Qty</u>		<u>Loc Code</u>					
				FG023		1							
				71666		1							
DT8439 		Manufactured	No			120	Each	0.0000	1	1			
template													

